



# Acer Aspire 4520-5464 Graphics Card Replacement

How to replace or upgrade the Graphics Card of an Acer Aspire 4520-5464 laptop.

Written By: Hunter Gilcrease



## INTRODUCTION

This guide will show you how to replace or upgrade the Graphics Card of an Acer Aspire 4520-5464 laptop. The graphics card allows graphics to be displayed on the screen of the laptop.

---

### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
  - [Flathead 3/32" or 2.5 mm Screwdriver](#) (1)
-

## Step 1 — Battery



- Shut down the computer and disconnect all external devices and cables.
- Flip the computer over.

## Step 2



- Ensure that the battery compartment lock tab is in the unlocked position.
- Slide the sliding black tab away from the battery compartment.
- The inside edge of the battery should be released, causing it to slightly pop out of the compartment.

This document was generated on 2020-11-28 06:22:30 AM (MST).




## Step 3




- Grasp the inside edge of the battery and lift to fully detach the battery from the computer.

## Step 4 — Graphics Card




- Using a Phillips PH1 screwdriver, remove the seven 0.5mm screws from the largest panel on the back of the laptop.
- ☑ Set the screws aside.
- Lift up the panel from the indent located on the right side.

## Step 5



- Unscrew the four 0.5mm Phillips #1 screws located on the heat sink in numerical order, as labeled on the device.



## Step 6



- Using the traditional 2.5mm screwdriver, rotate the locking tab counterclockwise to unlock the graphics card.



## Step 7



- Lift up the heat sink line and remove the graphics card.

To reassemble your device, follow these instructions in reverse order.