




Aquaris M5 Daughterboard Replacement

This Guide shows you how to replace the daughterboard of your bq Aquaris M5

Written By: Theo Mat



INTRODUCTION

Use this guide to replace the daughterboard of your bq Aquaris M5.

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Spudger](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
 - [iOpener](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Back Cover



- Insert the tip of an iFixit opening tool between the back cover and the mid frame of the phone.
 - ⓘ Between the 2 SIM card slots is a good place to start.
- Slide the opening tool to the bottom of the phone, to snap out the plastic clips, connecting the back cover and mid frame.


Step 2



- Slide the opening tool back to the top of the phone, to disconnect all the clips on the edge.
- Slide around the corner and along the top edge, to also disconnect these clips.

Step 3



 Be careful not to bend the back cover too hard to prevent some of the clips breaking.

- Grab the back cover by the loosened edge.
- Gently bend and twist the flexible back cover a bit to disconnect the remaining clips.
- Take off the back cover.

Step 4 — Battery



- ❗ Damaging the liquid indicator sticker, on the middle most screw, will void the warranty of the phone.
- Unscrew the ten black 4mm Phillips #00 Screws from the mainboard shield.
- Unscrew the golden 3.4mm Phillips #00 screw on the middle-right side of the mainboard shield.

Step 5




- Insert the flat side of a spudger between the mainboard shield and the frame of the phone.
- Twist the spudger to lift up the mainboard shield.
- Remove the mainboard shield from the phone.

Step 6




- Use a spudger to disconnect the battery's flex cable from the mainboard.
- Pull off the sticker on the bottom side of the battery.
- Grab the sticker and lift it up to take the battery out of the phone.

Step 7 — Loud Speaker




- Take out the seven 4mm Phillips #00 screws, holding the loud speaker unit to the mid frame of the phone.

Step 8




- Insert the flat side of a spudger into the gap on the right side of the loud speaker.
- Lever the loud speaker up with the spudger.
- Grab the loud speaker and take it out of the phone.

Step 9 — Daughterboard



- Use tweezers to disconnect the antenna cable from the daughterboard.
- Unscrew the black Phillips #00 screw, that holds the power and volume buttons in place.
- Use the flat end of a spudger to disconnect the flex cable from the mainboard.

Step 10



- Grasp the flex cable by the connector and carefully peel it off.
 - ❗ You can use a spudger to loosen the adhesive with the other hand.
- Use a spudger to lever out the daughterboard.
- Remove the daughterboard.

To reassemble your device, follow these instructions in reverse order.