




PowerBook G4 Aluminum 17" 1.67 GHz (High-Res) Hard Drive Replacement

Replace the hard drive in your PowerBook G4 Aluminum 17" 1.67 GHz (High-Res).

Written By: Walter Galan



INTRODUCTION

Upgrade your hard drive for more storage space.


TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)
- [T8 Torx Screwdriver](#) (1)

PARTS:


- [160 GB 5400 RPM ATA Hard Drive](#) (1)
- [320 GB 5400 RPM ATA Hard Drive \(New\)](#) (1)
- [G4 Aluminum 17" 1.67 GHz \(HR\) Hard Drive Bracket & Cable](#) (1)

Step 1 — Battery




- Use your thumbs to push the two battery retaining tabs away from the battery.
- The battery should pop up enough to rotate it toward yourself and lift it out of the lower case.

Step 2 — Memory Door



- Remove the three 2.3 mm Phillips screws securing the memory cover to the lower case.

Step 3




- Lift the memory cover slightly and pull it toward yourself to remove it from the lower case.

Step 4 — Upper Case



- Remove the following ten screws:
 - Two 14.7 mm shouldered Phillips.
 - Three 12.3 mm Phillips.
 - One 3.8 mm T8 Torx.
 - One 6.8 mm T8 Torx.
 - Three 1.3 mm Phillips.

Step 6



- Use the tip of a spudger to slide the trackpad ribbon cable out of its socket.

Step 7




- Remove the four 3.4 mm Phillips screws from the PC card side of the PowerBook.
- ✦ When replacing these screws, you must reinstall each screw in the correct order. Begin by installing the screw closest to the display hinge, and go out from there.

Step 10



- Starting near the display, lift the upper case straight up off the lower case, minding any cables that may get caught.

Step 11 — Hard Drive




- Use the flat end of a spudger to pry the sound card ribbon cable connector up off the logic board.
- Move the sound card ribbon cable away from the face of the hard drive.
- ⓘ It is not necessary to disconnect the sound card ribbon cable from the sound card.

Step 13




- Remove the following four screws:
 - Three 11.1 mm T8 Torx.
 - One 3.9 mm T8 Torx.
- Lift the hard drive out of the lower case.

Step 14 — Hard Drive




- Pull the hard drive cable straight away from the hard drive. It is helpful to wiggle the connector while pulling it away from the hard drive.
- ⓘ If you happen to bend the hard drive pins during removal, use the connector as a guide to bend them straight.

Step 15



- Remove the two Phillips screws from the right side of the hard drive.
- Pull the right hard drive bracket away from the hard drive.

Step 16



- If necessary, peel the piece of tape holding the left hard drive bracket to the hard drive shield off the hard drive shield.
- ⓘ It is not necessary to completely remove this piece of tape.
- Remove the two Phillips screws from the left side of the hard drive.
- Pull the hard drive bracket away from the hard drive.

Step 17



- Use the flat end of a spudger to separate the adhesive holding the hard drive shield on the hard drive.

Step 18



- Pull the hard drive shield off the hard drive.

To reassemble your device, follow these instructions in reverse order.