


Altec Lansing Mini Lifejacket 2 Motherboard Replacement

Use this guide to replace the motherboard in...

Written By: Stephen Albrecht



INTRODUCTION

Use this guide to replace the motherboard in your Altec Lansing Mini Lifejacket 2 if the bluetooth chip, microphone, or another electronic component has failed.

TOOLS:

Phillips #2 Screwdriver (1)

Phillips #1 Screwdriver (1)

Metal Spudger (1)

Tweezers (1)

Spudger (1)


Step 1 — Back Panel








 Use the spudger to remove the eight black pins from the front and back of the wire screens.







- Detach the eight secondary pins from the front and back of the wire mesh plates with a spudger.
- (i) Removing the secondary pins from the rubber casing is optional.

Step 3





Remove both black and orange layers from the speaker body.







- Remove the single 7.8mm Phillips #2 screw from the mounting plate located under the device.
- Slide the mounting plate out to remove it.


Step 5





Pry off the wire mesh on both sides using a metal spudger.

 \triangle Be gentle to avoid bending the mesh.





• Using <u>tweezers</u>, remove the four rubber stoppers in each corner of the rear panel.

Step 7



Remove the four 13.7mm
Phillips #1 screws located underneath the rubber stoppers.



 Pull the case apart to access the interior components.

Step 9







• To remove the back panel, gently pull out its wire harness.

Step 10 — Battery








- Disconnect the battery from the motherboard.
- (i) The battery is not secured within the case and can be removed after detaching its wiring from the circuit board.


Step 11 — Motherboard







Unplug the remaining four wire harnesses attached to the circuit board



• Remove the three 9.1mm Phillips #1 screws located on the circuit board.

Step 13



• Remove the motherboard.

To reassemble your device, follow these instructions in reverse order.