




Dell Vostro 1710 Fan Replacement

A instruction on how to replace the fan.

Written By: Tangxiao Sun



INTRODUCTION


The fan helps the laptop remove the heat it produces and keeps your laptop from overheating. If your computer keeps overheating you will need to replace the fan. This guide will walk you through on how to replace the fan using only a #1 Philips head screwdriver.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Battery




- ❗ Make certain that the power to your laptop is off.
- Press and slide the two buttons outwards and away from the battery.

Step 2





- Slide the battery away and parallel from the laptop.

Step 3




- Remove the battery from the slot.

Step 4 — Back Panel





- Unscrew the eight 6mm screws with a Philips #1 screw driver.

Step 5





- Lift back cover from the groove on the left side of the cover next to the symbol.

Step 6 — Fan





- Unclip the power supply by pulling the cable directly up and out of the socket.

Step 7



- Remove the two 3mm screws located around the edge of the fan with a Philips #1 screw driver.

Step 8



- Gently lift and pull to the left until the fan is free from the heatsink.

To reassemble your device, follow these instructions in reverse order.