



2001-2006 Mini Cooper Door Handle and Small Speaker Disassembly

This is a guide of how to remove the door handle and small speaker assembly to either replace those parts or get access to the other components of the door.

Written By: Eliot Kahn



INTRODUCTION


In order to access the inner components of the car door, like the door lock actuator and window assembly, you will need to remove the handle and speaker.



TOOLS:


- [Phillips #2 Screwdriver](#) (1)
 - [Flathead Screwdriver](#) (1)
 - [T30 Torx Driver](#) (1)
-

Step 1 — Door panel





- The first step is to remove the door handle and speaker cover. This is easily done by prying it off the plastic tabs with a flathead screwdriver or possibly even your hands.
- Next you need to remove the four size T30 torx screws that hold the panel in place. Three of these are in the obvious screw holes shown but the last is hidden behind the colored reflector, which you will need to pry off. It is easy to remove with a small flathead screwdriver. Of the four screws, two are 18mm and the other two are 52.5mm long.

Step 2




- With the screws removed, you will need to pry the panel off of the door using a prybar or flathead screwdriver. I wrapped my screwdriver in electrical tape to keep it from scratching the car.
- The bottom and sides of the panel are held on with one type of clip while the top is held on by another. Because of this, you want to start prying it somewhere along the bottom edge of the panel, I chose the lower outside corner.

Step 3



- Once you have the bottom and sides of the panel popped off the tabs, you want to to a combination of lifting and pulling along the top edge to remove it from these other types of tabs.
- Once the panel is free from these, you can slide it over the door lock knob and pull the whole thing away.
- That's it. You now have access to the rest of the door. In order to put the panel back on, just follow these directions in reverse order.

Step 4 — Door Handle and Small Speaker



- After removing the door panel, you will have access to the door handle assembly.
- This assembly is attached to the door with three Phillips screws, which you will need to remove.
- Once those screws are removed, the assembly is free from the door, allowing access to the door lock cable and the window actuator. Replacing the handle assembly requires screwing it back into the yellow screwholes shown.

To reassemble your device, follow these instructions in reverse order.