



Dirt Devil Scorpion Quick Flip Filter Adapter Replacement

This guide will allow you to replace the filter adapter within your Dirt Devil Scorpion Quick Flip hand vacuum.

Written By: Joseph Warner



INTRODUCTION

This guide will allow readers to replace the filter adapter on their Dirt Devil Scorpion Quick Flip hand vacuum. The primary reasons to change a filter adapter include improper suction or visible damage to the current filter adapter.

Step 1 — Filter Adapter



- First, press the button on the handle of the vacuum to separate the two halves.
- The button triggers a release mechanism, detaching the front half from the back of the vacuum.

Step 2



- Once the front half has been separated from the back half, locate the filter adapter.
- The filter adapter is attached to the filter, locating the filter in this step will sufficiently locate the filter adapter.
- Grasp the filter and adapter. Pull them out together.

Step 3



- Rotate the filter counterclockwise to remove it from the filter adapter.
- Once the filter adapter has been removed from the filter, replace it.

To reassemble your device, follow these instructions in reverse order.