



HP Officejet 4630 Paper Tray Replacement

How to replace a broken paper tray on the HP Officejet 4630.

Written By: Tyler Allen



INTRODUCTION


Paper trays are easy to break but thankfully it is an easy repair with only one tool required.



TOOLS:

- [T10 Torx Screwdriver](#) (1)
-

Step 1 — Paper Tray




- Begin by turning your printer upside down.
- ❗ It can be helpful to position an object beneath the printer to keep it level while you work on it.

Step 2





- Use the T-10 screwdriver to remove the two 11-mm screws.

Step 3



- Pull the paper tray out until it hits the stops on either side of the tray.



Step 4



- Lift up on one side of the black plastic bar with one hand while pulling the paper tray out of the printer with your other hand.


 The side of the tray should slide away from the printer a little bit.

Step 5



- Repeat the previous step but for the other side of the tray.

Step 6



- The paper tray should now be free to slide away from the printer.

To reassemble your device, follow these instructions in reverse order.