



Remove Trash Lid to stop ripping bags

Also, many people loved this can's form factor,...

Written By: Paul Tast



INTRODUCTION

Also, many people loved this can's form factor, but the bags ripped and the lid stopped working.

I fixed the lid from not working by opening it up, discovering the wires are tiny and low quality. The problem was detached soldering. And then I re-soldered it.

Step 1 — Here it is out.



- Just take it out. No more ripped trash bags.

To reassemble your device, follow these instructions in reverse order.