



Dell Vostro 2421 Battery Replacement

Written By: Johnathan Hammond



INTRODUCTION

In this guide, we will be showing you how to remove and replace the Battery.



PARTS:

- [Dell Inspiron \(3521/5421\) and Vostro 2421 11.1V Replacement Laptop Battery](#) (1)
 - [Dell Inspiron \(3521/5421\) and Vostro 2421 14.8V Replacement Laptop Battery](#) (1)
-

Step 1 — Removing the Battery



- Slide the release latches outwards to unlock the battery and lift the battery to remove it from the computer.