

Canon EOS Rebel T6i Battery Replacement

This guide will feature how to remove and replace the battery for the device.

Written By: Matthew Krahl



INTRODUCTION

This guide shows the process for replacing a battery on the Canon Rebel t6i. Troubleshoot the battery before obtaining a replacement. Make sure the charger is working and it is the right type of battery. If the old battery is punctured or damaged, Take precaution when disposing the battery as the contents may be toxic.



PARTS:

7.2V 1040mAh 7.5Wh Battery (1)

Step 1 — Battery Replacement Guide



- Open up the hatch labeled
 "Batt.Open " and pull the gray notch away from the battery.
- Remove the battery when it pops up out of its socket.
- Make sure to place the new battery into the device with the 4 brass strips first.

To reassemble your device, follow these instructions in reverse order.