



Dell Latitude E7470 SSD Replacement

Step-by-step tutorial to replace the internal SSD of a Dell Latitude E7470.

Written By: Hyperion



INTRODUCTION

Replacing the internal m.2 SSD of a Dell Latitude E7470. You can only choose a 2280 m.2 SSD, the other sizes are not compatible with this PC.



TOOLS:

- [philips screw driver 0](#) (1)
- [iFixit Opening Picks set of 6](#) (1)
- [Anti-Static Wrist Strap](#) (1)



PARTS:

- [1 TB GB M2 SSD](#) (1)

Step 1 — Open cover



- Begin by removing the 8 screws circled in red on the photo opposite with a Philips # 0 screwdriver.
- Next, using the iFixit Opening Picks, lift the cover up from the dock connector. Unclip it gently.

Step 2 — Changing the SSD



- After removing the cover, the SSD slot is on the bottom right, right next to the battery.
- ⚠ Make sure you have grounded yourself before you start handling. There is a huge risk of damaging components. Use an antistatic wrist strap.
- To remove the SSD, simply remove the single screw that holds it. Lift the SSD to a 30-degree angle and pull it from its slot.

To reassemble your device, follow the instructions in reverse order.