



Alcatel Pop 4 Plus SD Card Replacement

This guide will show you how to replace or insert a SD card in the Alcatel Pop 4 Plus.

Written By: Christopher Marcello



INTRODUCTION

This guide will help you locate where your SD card slot is on your Alcatel Pop 4 Plus and also show how to replace the SD card. All you need are your fingers to remove the outside cover and then slide the SD card in.

Step 1 — SD Card



- Remove the back cover by sliding your fingernail in the groove around the edge of the phone and prying it off.

Step 2



- Use your fingers to pull out the Micro SD card.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-28 06:40:04 AM (MST).

