



HP 15-R263DX Disassembly

This guide is a step by step tutorial on disassembling the HP 15 laptop to have access to internal components.

Written By: Dilan Johnson




INTRODUCTION

These are the required steps for disassembly in order to access internal components that may need replacement.

TOOLS:


- [Phillips #1 Screwdriver](#) (1)
 - [Metal Spudger](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Battery




- Eject the battery from the computer by sliding the two clips on the bottom of the computer toward the center of the computer.
- Slide the battery out as shown in the picture.

Step 2 — Optical Drive



- Using a Phillips #1 screwdriver, remove the small screw next to the disc engraving shown in the picture.

Step 3



- Gently slide the optical drive out of the side of the computer.

Step 4 — HP 15-R263DX Disassembly



- Locate the two corner grips on the hinge side of the computer.
- Using a metal spudger, remove the two corner grips to reveal the screws.

Step 5




- Remove the 11 small screws on the bottom of the computer that are shown in the picture.

Step 6



- Remove the 2 small screws that are on the bottom side of the disc tray slot.
- ⓘ These screws are shorter and wider than the others.

Step 7



! Once the keyboard is loose, do not immediately pull away from computer. It is attached by the ribbon connector.


- Using a spudger, pry around the edges of the keyboard until all clips are disengaged and the keyboard is loose from the computer.
- To disconnect the ribbon connector, flip up the black clip shown in the picture.
- Gently pull the ribbon until disconnected.

Step 8



- Disconnect the other two ribbon connectors underneath the keyboard by flipping up the black clips.
- Remove the 4 small screws shown in the picture.

Step 9



- Disengage the face plate clips by prying the case away from around the outer edge of the face plate with a metal wedge.
- The face plate can then be lifted away from the computer.

To reassemble your device, follow these instructions in reverse order.