# Dell Inspiron 14 7460 Battery Replacement

Written By: Terrence15

| www.iFixit.com |

INTRODUCTION

In this guide, we will show you how to remove and replace the Battery.

🔧 **TOOLS:**

- Essential Electronics Toolkit (1)

⚙️ **PARTS:**

- Dell WDX0R Replacement Battery (1)

This document was generated on 2021-12-09 11:50:16 PM (MST).

Step 1 — Disconnecting the Battery Cable

⚠ WARNING: Before working inside your computer, read the safety information that shipped with your computer and follow the steps in <u>Before Working Inside Your Computer</u>. After working inside your computer, follow the instructions in <u>After Working Inside Your Computer</u>.

- Disconnect the battery cable from the system board.

Step 2 — Remove the Screws

- Remove the four screws (M2x3) that secure the battery to the palm rest and keyboard assembly.

This document was generated on 2021-12-09 11:50:16 PM (MST).

Step 3 — Lifting the Battery

- Lift the battery off the palm rest and keyboard assembly.

Step 4 — Grounding the System Board

- Press and hold the power button for five seconds to ground the system board.

Step 5 — Align the Screw Holes

- Align the screw holes on the **NEW** battery with the screw holes on the palm rest and keyboard assembly.

Step 6 — Replace the Screws

- Replace the four screws (M2x3) that secure the battery to the palm rest and keyboard assembly.

This document was generated on 2021-12-09 11:50:16 PM (MST).

Step 7 — Connecting the Battery Cable

- Connect the battery cable to the system board.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2021-12-09 11:50:16 PM (MST).