



# Epiphone ES-335 PRO Pickguard Replacement

Replace your cracked or broken pickguard to make your guitar look new again.

Written By: Michaih Ley Bayani



---

## INTRODUCTION

Follow these steps to replace the pickguard on your Epiphone ES-335 PRO electric guitar. This may be necessary because the pickguard is chipped or broken due to an accident. You may also want to change the pickguard to change the design of the guitar.

---

### TOOLS:

- [Phillips #2 Screwdriver](#) (1)

## Step 1 — Pickguard



- Locate the screw closest to the neck of the guitar.
- Use a phillips head #2 screwdriver to completely unscrew the 1.0 mm length screw.
- ⓘ Be sure to keep any screws together as you will use them again, unless the replacement pickguard has its own screws.

## Step 2



- Using a phillips head #2 screwdriver, completely unscrew the 1.0 mm length screw.
- Gently lift the pickguard off the body of the guitar.

To reassemble your device, follow these instructions in reverse order.