



Archived

# Dell Precision M3800 Base Cover Replacement

Written By: Johnathan Hammond



---

 **TOOLS:**

T5 Torx Screwdriver (1)

---

### Step 1 — Base Cover



- Turn the system badge flap over and place it on the base cover.
  - Remove the screws that secure the base cover to the computer. Release and remove the base cover from the computer.
- (i) NOTE:** To remove the screws from the base cover, use a T5 Torx screwdriver.
- Lift up and remove the base cover from the computer.

---

To reassemble your device, follow these instructions in reverse order.