



# Dell VRC100-R Joystick Replacement

How to replace your joystick to increase mobility on the Dell VRC100-R controller.

Written By: Kenneth Liu



---

## INTRODUCTION

Do you have a sticky joystick? Fix it here! Dirt buildup and long-term use cause sticky joysticks. For this guide, you will need a plastic opening tool.

---



### TOOLS:

- [iFixit Opening Tools](#) (1)
-

## Step 1 — Joystick



- Hold the joystick down with your left thumb to make space for the plastic opening tool.
- Insert the plastic opening tool into the circle above the joystick and pry upwards to lift the front panel.
- Slide the plastic opening tool around the perimeter until you can lift the front panel.
- ❗ You may hear a popping noise when you pry off the front panel.

## Step 2



- Grab the joystick and pull away from the controller to remove it.

To reassemble your device, follow these instructions in reverse order.