



# Asus Chromebook C201PA-DS02-LG Keyboard Replacement

How to replace a keyboard on your Asus Chromebook C201PA-DS02-LG.

Written By: Brittany M Won



---

## INTRODUCTION

Are your keys not clicking? Did you spill any liquids on your keyboard recently? This guide will help you resolve these situations.

---

### TOOLS:

- [iFixit Opening Tools](#) (1)
  - [Metal Spudger](#) (1)
  - [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Keyboard



- Use a metal spudger to pry off the two feet closest to the hinge of the laptop.
- ☑ The feet are attached to the laptop by adhesives, therefore they may not stick as well after multiple removals.

## Step 2



- Use a Phillips #0 screwdriver to unscrew the six 5mm screws.
- Use a Phillips #0 screwdriver to unscrew the two 6mm screws.

### Step 3



- Use a plastic opening tool to pry the keyboard off the edges of the computer.

**i** The edges will make a popping noise.

### Step 4



- Flip up the white bar that connects the thin white strip using a plastic opening tool.
- Grab the thin white strip and pull straight back to remove the strip from the connector.

## Step 5



- Use a plastic opening tool to lift the black bar above the wide black strip in the connector.
- Grab the wide black strip and pull straight back to remove the strip from the connector.
- Remove the keyboard by lifting it straight up.

To reassemble your device, follow these instructions in reverse order.