



# Yuneec Typhoon H Landing Gear Replacement

After completing this guide, the landing gear on the Typhoon will be replaced, and you will be able to fly and land successfully.

Written By: Shasta Banchio



---

## INTRODUCTION

Learn how and where to unscrew the landing gear legs in order to replace broken ones, without breaking your drone more.

---

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Landing Gear



- Lift all drone arms up so you can access the landing gear easily.

## Step 2



- Unscrew the 16.9 mm screw at the top of the landing leg with a Phillips #00 screwdriver.
  - ⚠ Make sure the screw head is not stripped in the process.
    - If stripped, the whole leg, including the internal sensors, will need to be replaced.

### Step 3



- Pull the landing leg out slowly and remove it from the device.

Your Yuneec Typhoon H should now be ready to fly safely again.