



Acer One 10 S1003-114M Key Replacement

Do you have a key that is broken or has worn...

Written By: Rachel Harrison





INTRODUCTION

Do you have a key that is broken or has worn markings? If so, use this guide to replace a key.

TOOLS:

[Tweezers](#) (1)

Step 1 — Key



- Make sure your device is powered off and disconnected from any power supply.
- Open the laptop and disconnect the tablet screen from the magnetic keyboard dock by gently lifting the screen up.
- Use [tweezers](#) to gently pry up the damaged key.

Step 2



⚠ White plastic springs may become misaligned when removing key.

- If the plastic springs do become misaligned, use tweezers to realign springs by popping them back into their horizontal placement.

To reassemble your device, follow these instructions in reverse order.