

Kobo Mini Disassembly

This e-reader is good.

Written By: Gabriel Bédard





• 64 Bit Driver Kit (1)

Step 1 — Kobo Mini Disassembly





Pull on the corner to remove the cover.

Step 2



- Remove the six screws.
- Remove the back of the device.

Step 3



- Remove the four screws from the mother board.
- Remove the screen connector and the battery connector.
- Remove the micro SD card.
- Remove the motherboard from the chassis.

Step 4



- Remove the four screws from the screen frame.
- Remove the screen

Step 5



And we finally finished.