



# Battery disassembly

Written By: Roberto Bartolacci



## Step 1 — Remove the battery



- Turn the laptop upside down and gently lay it down on a flat surface.
  - Slide the battery release latch to the right and the battery will pop up slightly.
  - While keeping the latch slid with one hand, grab the battery with the other hand and remove it by pivoting it upward.
- i** *At this point some users would turn the laptop upside down once again and press the power button a couple of times. They say that this should help dissipating all of the remaining electricity around the device. Up to you :)*

To reassemble your device, follow these instructions in reverse order.