



Dell Inspiron 17R-N7010 Battery Replacement

In this guide you will learn how to find and...

Written By: Brandon Lopez



INTRODUCTION

In this guide you will learn how to find and replace the battery in a Dell Inspiron 17R-N7010 laptop. Battery replacement is needed when you notice signs of battery failure such as not holding a charge for as long, taking longer to charge, not charging at all, or not powering on. This replacement is very basic and requires no tools.

⚙️ PARTS:

[Dell Inspiron 17R-N7010 Battery \(1\)](#)

Step 1 — Battery



- Flip over the laptop so the back is facing upwards.
- Locate the battery compartment.
- ⚠️ Make sure your laptop is turned off before disassembly.

Step 2



- Slide both locks away from the center of the battery.
- After you hear a click, pull out the battery.

To reassemble your device, follow these instructions in reverse order.