



# Canon EOS 60D Left-Side Port Cover Replacement

This guide will show how to remove the port cover, and side of the camera.

Written By: Eric D



---

## INTRODUCTION

This will allow you access to the ports, or if you need to replace the dust cover, will allow you to do that.

---

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — Rubber grips



- Use a thin piece of plastic, spudger, or fingernail (if you have them) to lift up the edge of the grip, and pull up slowly.
- Repeat for the other two grips
- ⓘ The large one on the battery-side is the easiest to start with. This is required to remove the front & back panels
- ⓘ The small one on the back is a bit difficult to get started, but not really difficult to remove.
- ⓘ The one on the AV panel will be easier if you open up the AV port cover.
- Remove the adhesive like you would rubber cement, just rub your finger against it, it will come off.
- Optionally throw the balled up adhesive at people pretending its a booger :)

## Step 2 — Left-Side Port Cover



- Remove 3 screws

## Step 3



- Remove the small Screw under the Flip cover too

## Step 4



- Using a Spudger, fingernail, or other thin plastic tool to wedge the panel off of the camera
- Start at the camera's front. Pulling on the rubber av-cover may be enough to get it to move off the body
- Only pull about 1/4" (3-5mm). There is a tab that will need to slide out

## Step 5



- Slide the rear part of the cover out.

## Step 6



- At this point, the only thing holding on is the dust-cover is hooked onto the front panel
- Slide down to remove without damaging the cover. (see photo with cover removed)
- You can see how the cover, and side piece fit together in the second image.

To reassemble your device, follow these instructions in reverse order.