



Acer Aspire 4741G-332G32Mn Battery Replacement

By following this guide you will be able to replace the battery in the Acer Aspire 4741G-332G32Mn.

Written By: Christopher Carstairs



INTRODUCTION

If your Acer Aspire 4741G-332G32Mn is not holding its charge, it probably needs a battery replacement. These instructions will help you to quickly remove the battery with minimal skill or effort.

When a battery is working correctly it should provide the laptop with power for several hours without being plugged into a power source. After several cycles of being charged, the battery will begin to lose the ability to hold a charge. You can check the charging capacity by calibrating your battery. If there is a drop in the battery percentage, you should consider replacing the battery.

Be sure the laptop is powered off before replacing its battery.

Take appropriate precautions if the battery is swollen. Beware of punctured batteries as they can cause fires.



PARTS:

- [Acer Aspire \(4741G/5741/7741\) and TravelMate \(8572/8472\) Replacement Laptop Battery](#) (1)
-

Step 1 — Battery



- Flip the lock latch to unlock battery.

Step 2



- Slide the middle latch and remove the battery.

To reassemble your device, follow these instructions in reverse order.