



2008-2015 Chevrolet Cruze Sway Bar End Links Replacement

This job can be done at home. I will show you some tips and tricks to help you thru the process and also show you where things can get problematic.

Written By: OneTrick





TOOLS:

- [Impact Wrench](#) (1)
- [Socket 18mm](#) (1)
- [19mm Deep Socket](#) (1)
- [Mini Locking Pliers](#) (1)
- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Penetrating Lubricant](#) (1)



PARTS:

- [Front Sway Bar Link Kit](#) (1)

To reassemble your device, follow these instructions in reverse order.