



# HP Chromebook 14-x013dx Motherboard Replacement

How to replace the motherboard in an HP Chromebook 14-x013dx.

Written By: Eile Woeltje



---

## INTRODUCTION

This guide describes how to replace a faulty motherboard in an HP Chromebook 14-x013dx. A malfunctioning motherboard could be due to overheating or other damage to the laptop. This replacement involves removing the laptop's keyboard, and the total repair time should take about 25 minutes.

---

### TOOLS:

- [Spudger](#) (1)
  - [Phillips #00 Screwdriver](#) (1)
-

## Step 1 — Keyboard, Touchpad



- Using the plastic spudger, gently lift the 5 rubber pads away from their seating.

## Step 2



- Remove the five 6mm screws located under the removed pads using Phillips #00 screwdriver.

### Step 3




- With the Phillips #00 screwdriver, remove the remaining eight 6mm screws. You will now have thirteen 6mm screws removed from the case.

### Step 4




- To continue removing the back cover, turn the laptop over as displayed.
- Use the plastic spudger to gently pry around the base of the laptop from the back cover. Continue prying around the entire base of the laptop.

## Step 5





- Gently lift the silver base of the laptop from the bottom, but do not remove it.
- To remove the ribbon cables, lift the latch holding the ribbon cables in place and then pull them free.
- Remove the keyboard panel from the laptop.

## Step 6 — Battery




- Remove the eight 4mm screws holding the battery in place using the Phillips #00 screwdriver.

## Step 7



- Remove the ribbon cable that runs over the battery by lifting up the plastic latches and pulling the cable away.

## Step 8






- Unhook the battery's power connector from the motherboard.

## Step 9



- Lift the battery out of the laptop case.

## Step 10 — Motherboard



- Carefully remove the 4 connections.

## Step 11



- Using a Phillips #00 screwdriver, remove the seven 2mm screws holding the motherboard in place.
- Gently lift the motherboard out of the laptop case.

To reassemble your device, follow these instructions in reverse order.