



Toshiba Satellite L305-S5875 Battery Replacement

This guide will show how to remove and replace the battery of your Toshiba Satellite L305-S5875 laptop.

Written By: Juan



INTRODUCTION

Replace the Toshiba Satellite L305-S5875 battery to provide power to the laptop.

Step 1 — Battery



- Close the laptop lid and flip the laptop over.
- Switch the lock button on the left to the unlock position. (The unlock position is to the left side.)

Step 2



- Push the release button to the right.
- Hold the release button to the right and lift the battery out of its housing.

To reassemble your device, follow these instructions in reverse order.