

## **DROCON Ninja Battery Replacement**

How to replace the battery of a DROCON Ninja DC-014.

Written By: Taylor Ullmann



## **INTRODUCTION**

This guide is intended to help you replace the battery of the DROCON Ninja DC-014. The drone's battery provides power to the motors. If you notice reduced performance in flight consider replacing the battery. The battery might need to be replaced if the <u>drone is not charging or is losing battery quickly</u>. You will not need any tools for this guide and there are no difficult steps required. If the battery is swollen take extra care when removing it.

## Step 1 — Battery







- Make sure the drone is powered off before beginning the battery replacement.
- To turn the drone off, press and hold the black button on the top of the drone until all lights are off.
- Firmly grasp the battery tab between your thumb and index finger.
- Pull the battery away from the drone's body

To reassemble your device, follow these instructions in reverse order.