



Nokia 5130 XpressMusic Rear Panel Replacement

The back panel might get scratched up, or stop holding on and you might need to replace it.

Written By: iSzymon



Step 1 — Sliding off the rear panel



- Slide the rear panel in the indicated direction to unlock it.

Step 2 — Lifting up the rear panel



- After unlocking it, the rear panel can now be lifted up.

To reassemble your device, follow these instructions in reverse order.