



# MasterCraft Eliminator Waterproof Spotlight Battery Replacement

This guide will show you how to replace the battery of a MasterCraft Eliminator Waterproof Spotlight.

Written By: Sumaiya Islam Rosema



## INTRODUCTION

If your MasterCraft Eliminator waterproof Spotlight is not working ,then use this guide to replace the battery of the spotlight .

With times, the battery gets weak as a reason it doesn't work properly .But most of the people throw the spotlight thinking that it can not be change and buy new one. This guide will help people how easily the battery can be change with low cost and at the same time money can be save from not throwing the spotlight.

Before using this guide, inspect the spotlight is it has any other problems or not. Typically, if the spotlight body has dust then can be removed using brush or small dust blower .

---

### TOOLS:

- [Latex or nitrile gloves](#) (2)
  - [JIS #00 Screwdriver](#) (1)
-

## Step 1 — Battery



- Twist the front cover of the spotlight in a counter-clockwise rotation and remove it from the device.

## Step 2



- Remove the rear piece which is the protection cover for the charging port.

### Step 3



- Using the JIS #00 screwdriver, remove the two screws securing the motherboard to the device.

### Step 4



- Using the JIS #00 screwdriver, remove the single screw securing the charging port and remove the charging port from the device.

## Step 5



- Carefully disconnect the battery and remove it from the device.

To reassemble your device, follow these instructions in reverse order.