



Lenovo 500e Chromebook 2nd Gen Back Panel Replacement

How to replace the back panel on a Lenovo 500e Chromebook 2nd Gen laptop.

Written By: Kristen Gismondi





TOOLS:

- [iFixit Opening Tool](#) (1)
- [Phillips #0 Screwdriver](#) (1)

Step 1 — Back Panel



- Remove nine 6 mm screws from the bottom cover of the laptop using a Phillips #0 screwdriver.

Step 2



- Remove stylus from the lower left corner of the back panel.

Step 3



- Go along the edge of the back panel with an iFixit opening tool until it pops loose.
- Remove the back panel from the laptop.

To reassemble your device, follow these instructions in reverse order.