



# LG Escape (p870) Loudspeaker Assembly Replacement

This guide will show you how to repair or replace the loudspeaker assembly on your LG Escape (p870).

Written By: Brad



 **TOOLS:**

- Phillips #00 Screwdriver (1)
- Flathead 3/32" or 2.5 mm Screwdriver (1)

## Step 1 — Battery



- Turn the device over and pull the back plastic cover off by inserting your fingernail into the opening at the bottom of the phone and gently pulling.

## Step 2



- With your finger and from the bottom edge, lift the battery out of the phone and set it aside.
- You now have access to:
  - Your SD card
  - Your SIM card
  - Your device's serial numbers

### Step 3 — Loudspeaker Assembly



- Remove the 4 Phillips 00 screws securing the speaker assembly to the phone housing.

### Step 4



- Carefully insert a small flathead screwdriver between the speaker assembly and the rear housing
- Pry the speaker assembly out of the phone and set it aside

To reassemble your device, follow these instructions in reverse order.