



# Timbuk2 Messenger Bag Male Cambuckle Replacement

How to replace a broken male cambuckle piece on any Timbuk2 Messenger bag.

Written By: Emilee





## PARTS:

- [New Male Cambuckle](#) (1)

*Request through Timbuk2 customer service department*

## Step 1 — Male Cambuckle



- Does your Messenger Bag's cambuckle look like this? Well here's how to fix it!
- All you'll need is a new male cambuckle, which you can get from [Timbuk2's customer service department](#).

## Step 2



- Remove broken cam buckle. Un-thread strap from bottom plastic loop and take strap off.

### Step 3



- Thread strap into new cam buckle through the buckle's top opening. Pull strap through the bottom of the buckle, ensuring that the strap goes in **FRONT** of the connectors as shown.
- Make sure the strap is not twisted or facing the wrong way when inserting the new cambuckle!

### Step 4



- Snap buckle into female cam buckle and close the buckle.



## Step 5



- Thread strap through the bottom of the plastic loop (the loop where the strap was thread though before).
- Next, thread end of strap through the top end of plastic loop and pull to desired length.

## Step 6



- Congrats! You're all done!