



Panasonic PV-GS9 Battery Replacement

Written By: Trevor Johnson



INTRODUCTION

The first step in the repair process for the Panasonic PV-GS9 is to remove the Battery from the Camcorder.

Step 1 — Battery



- i** While holding the Camcorder firmly, pull down on the battery removal tab located on the underside of the camcorder.

Step 2



- Then, pull the battery down away from the camcorder. Pull out as it becomes free.

To reassemble your device, follow these instructions in reverse order.