



Dell Optiplex GX620 Side Panel Disassembly

This guide will show you how to remove the side panel from a Dell Optiplex GX620.

Written By: Kristina



INTRODUCTION

To access all other parts, you must first remove the cover.

Step 1 — How to unplug and discharge before repair



- Power down your PC and remove the power cord from the back.

Step 2



- Press and hold the power button for about 10 seconds, then release.
 - ⓘ This helps drain any remaining power stored in the capacitors, so that you can safely work on the internal components.

Step 3 — Dell Optiplex GX620 Side Panel Disassembly



- With the computer standing upright, firmly pull on the tab at the back of the computer.
- When the side panel pops free, gently pull the panel away from the computer.
- ❗ If you have trouble freeing the side panel from the case, you may need to pull the tab a bit harder.

To reassemble your device, follow these instructions in reverse order.