

# LG Optimus G Pro Rear Facing Camera Replacement

This will allow you to replace the Rear-Facing camera on your LG Optimus G Pro.

Written By: Wesley Pate



This document was generated on 2020-11-27 11:31:27 PM (MST).

# **INTRODUCTION**

After completing the inner cover, you can access the rear-facing camera.



# **TOOLS:**

- iFixit Opening Tools (1)
- Phillips #0 Screwdriver (1)

#### Step 1 — Remove Back Cover.



- Make sure before you begin working on your device, that the device is not charging.
- Once you have access to the phone, there is a small indent on the bottom left side. Use your fingernail or a plastic opening tool to pry from here and pull off the back casing.

#### Step 2 — Remove the Battery.



- Once you have properly removed the outer casing, the back should look as so.
- To remove the battery, pull up from the red mark using your finger. The battery should come up at an angle, and easily be able to be removed.
- Once the battery is removed you may safely proceed to the next step.

## Step 3 — Screw Removal





• Make sure you remove the battery first. You will see that there are 14 screws on the back of the inner case. Use the Phillips head screwdriver to remove each of the screws, make sure to put the screws in a safe place where they will not get lost.

## Step 4 — Remove Cover



- Once you have removed all the screws, you can begin removing the inside cover.
- Insert the opening tool using a sliding motion into one of the corners and move it along the edges of the inside cover. This will loosen the edges and the inside cover will pry apart from the shell.

# **Step 5** — Completion



 The inner cover is now removed, you now have access to the many parts on the inside of the phone.

## Step 6 — Remove the Ribbon Cable



 Using a plastic opening tool, pry the connection between the cable and the phone. With even pressure the cable should disconnect from the logic board easily.

## Step 7 — Remove the Camera



After removing the the Ribbon
 Cable, the Rear-Facing Camera
 should be able to be removed easily
 with your fingers.

To reassemble your device, follow these instructions in reverse order.