Nerf Recon CS-6 Plunger Replacement

With this guide you can replace the plunger.

Written By: Asad Qureshi

INTRODUCTION

The plunger works with the main spring to launch the dart. The o-ring creates a tight seal to stop air from leaking out when the main spring is compressed. This allows for a more powerful shot.

🔧 TOOLS:

- Phillips #0 Screwdriver (1)

This document was generated on 2020-11-28 08:19:18 AM (MST).

Step 1 — Remove Magazine

- (i) Skip this step if magazine is already removed.

- Pull slide back.

- Pull backwards on release buttons and slide magazine out.

- Push slide back forward and pull trigger.

Step 2 — Remove Visible Screws

- Use the Phillips #0 Screwdriver to remove these 9 screws.

- All screws marked in red are 9.6 mm Phillips #0 screws.

- Note that left most screw is longer than the rest and is a 18.6 mm Phillips #0 screw.

This document was generated on 2020-11-28 08:19:18 AM (MST).

Step 3 — Remove Hidden Screws

- Pull slide back to reveal more screws.

- Remove these 2 screws.

- Push slide forward.

- Pull trigger to release compression of the main spring.

- Screws are 9.6 mm Phillips #0.

- (i) Pulling the trigger will keep spring from launching out of the gun when the two halves are separated.

This document was generated on 2020-11-28 08:19:18 AM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 4 of 8

Step 4 — Remove Plunger Cap

- Remove the screws on the plunger cap.
- Tug the plunger cap off.
- Screws are 9.6 mm Phillips #0.

Step 5 — Remove Slide Screws

- Remove the 2 screws on the slide.
- Screws are 9.6 mm Phillips #0.
- Hold the two halves of the gun together to prevent any springs from launching out.

Step 6 — Split the Gun in Half

- Pull the gun apart at the middle seam.

⚠ Watch for any springs that might launch out.

Step 7 — Remove Spring

- Pull the spring out the back of the gun.

This document was generated on 2020-11-28 08:19:18 AM (MST).

Step 8 — Removing Plunger Guide

- Lift the plunger guide straight up out of the gun.

Step 9 — Remove Plunger

- Pull the plunger out the back of the gun off of the inner piece.

Step 10 — Remove Other Half of Plunger

- Pull the remaining half of the plunger out the back of the gun.

To reassemble your device, follow these instructions in reverse order.