



Sony Vaio Fit 13A Heatsink + Fan Assembly Replacement

Written By: Marii



 **TOOLS:**

- [Metal Spudger](#) (1)
- [iFixit Opening Tool](#) (1)
- [Tweezers](#) (1)
- [Phillips #0 Screwdriver](#) (1)
- [Iso 90% Rubbing alcohol](#) (1)
- [Arctic Silver Thermal Paste](#) (1)

 **PARTS:**

- [Sony VAIO Fit Fan with Heatsink](#) (1)

Step 1 — Back Cover



- Starting with the laptop top-down, locate and remove the twelve 1mm Phillips #0 screws securing the back cover to the main body of the computer.

Step 2



- Use the Plastic Opening Tools or Metal Spudger to carefully loosen back cover from the body of the computer.


⚠ Be sure to avoid headphone jack when removing back cover by lifting cover away from computer and up.

Step 3





- Lift off back cover to access inner components of computer.

Step 4 — Fan





- Remove the three 1mm Phillips #0 screws surrounding the fan.
- Loosen the three 1mm Phillips #0 screws. These screws will stay captive to the heatsink.

Step 5



- Use tweezers to carefully unplug the fan connector.

Step 6 — Remove the Fan



- Use the Plastic Opening Tool to gently remove the heat sink and fan assembly from the computer.
- ✎ **Important:** Follow the [How to Apply Thermal Paste](#) guide to replace the thermal paste before reassembling your device.

To reassemble your device, follow these instructions in reverse order.