



Asus X551CA HDD, RAM, Wi-Fi, KB, Battery, CMOS Battery, Cooling System, Thermal Paste

Video Tutorial

How to disassemble, take apart the laptop if...

Written By: ZFix



***HDD, RAM
Battery, Wi-Fi
Coolyng system***

INTRODUCTION

How to disassemble, take apart the laptop if you want to change, upgrade Hard Disk Drive, Keyboard, Wi-Fi card, Battery, BIOS / CMOS Battery, Optical drive, etc.

Does NOT include any guidance for replacing the DDR3 SDRAM.

If your system overheats, you must open the laptop, clean the cooling system and change thermal paste / compound to the processor (CPU).

[video: <http://youtu.be/hsQFt9c6E0Q>]



TOOLS:

[Phillips #0 Screwdriver](#) (1)
[iFixit Opening Tool](#) (1)
[Spudger](#) (1)
[Arctic Silver Thermal Paste](#) (1)
[Isopropyl Alcohol](#) (1)



PARTS:

[Thermal Paste](#) (1)

To reassemble your device, follow these instructions in reverse order.