

Nokia 2115i keypad replacement

Removing and replacing the keypad.

Written By: Shane



INTRODUCTION

To replace the keypad, only a small amount of disassembly is required.



F TOOLS:

• Spudger (1)

Step 1 — Nokia 2115i Battery







- To prevent shock, press down on the power button located on the top of the phone until the phone shuts off.
- Press down on the small gray button located on the back of the phone.
- Slide the back plate down and off.

Step 2





- To remove the battery, begin by holding the phone sideways.
- Then, insert your thumb in the groove below the battery and push the battery up and out.

Step 3 — Faceplate







- Locate the spudger. A photo of the correct spudger is provided to the left.
- Turn the front of the phone to face you. Find the two small square holes on the bottom left and right sides of the faceplate.
- Insert the spudger into each square hole and push up to detach the face plate.

Step 4 — Removing the Keypad





- Note: The keypad will be loose and may fall off during this step.
- Pull the face plate up and off of the phone.
- To remove the keypad, simply lift it off the phone.

To reassemble your device, follow these instructions in reverse order.