



2012-2015 Honda Civic Honda Key Battery Replacement

Use this guide to replace a 2012-2016 Honda...

Written By: monica



INTRODUCTION

Use this guide to replace a 2012-2016 Honda Civic key remote battery.

🔧 TOOLS:

Phillips #0 Screwdriver (1)
Spudger (1)

⚙️ PARTS:

Panasonic CR1620 battery (1)

Step 1 — Honda Key Battery



- Lay the key down so that the Honda symbol is facing upward.
- Use a Phillips #0 screwdriver to remove one screw.

Step 2 — Pry the cover off



- Insert the flat end of your spudger into the notch in the side of the key/remote.
- Pry the key remote apart to remove the cover.

Step 3 — Replace the battery



- Before you remove the battery, note which side faces up (+ or -). You should install your replacement the same way.
- Remove the battery.
 - ⓘ Your key may contain either a CR1616 or CR1620 battery. In some cases, either type will work, but for the best results, replace it with the same kind of battery that originally came with your key.
- Install your matching new battery in the same orientation as the original.

Step 4



- Place the two halves of the remote cover back together.
- Press the unlock or lock buttons to make sure the remote is working.
- Place the screw into the hole and tighten with a Phillips #0 screwdriver.

To reassemble your device, follow these instructions in reverse order.