

HP Mini 1000 Battery Replacement

Replace the battery in your HP Mini 1000.

Written By: Walter Galan



INTRODUCTION

This guide will show you how to replace the battery in your HP Mini 1000.

Step 1 — Battery





- With the case closed, place the Mini 1000 top-side down on a flat surface.
- Push both of the battery release latches toward each other.

Step 2



 Lift the battery out of the Mini 1000 from the edge closest to the release latches. To reassemble your device, follow these instructions in reverse order.