



Samsung SGH-E317 Battery Replacement

Replacing a dead or faulty battery in the Samsung SGH-E317 phone.

Written By: Laura MacCarley



INTRODUCTION

This guide will show a simple replacement of the Samsung SGH-E317 dead or faulty battery.

TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Battery



- Remove the back panel by pressing up on switch, located at the top on the back of the phone.
- ⓘ You may want to use a plastic opening tool to help pry the back panel off.

To reassemble your device, follow these instructions in reverse order.