



# LG G Watch R Strap Replacement Replacement

This guide will list the steps on how to remove the spring bar that holds the watch's straps in place.

Written By: Westley Courchene



---

## INTRODUCTION

The straps can be replaced or changed when the style no longer suits you.

---

### TOOLS:

- [Flathead Screwdriver](#) (1)
  - [Spring Bar Removal Tool](#) (1)
-

## Step 1 — Strap Replacement



- i** The straps are fastened to the watch with a spring bar, which can be collapsed when force is placed on the bar's edge.
- Pull the strap back to reveal the edge of the spring bar.
  - With a Flathead Screwdriver or Spring Bar Removal Tool, press down on the edge of the spring bar and pull it back until it comes out of its socket.

## Step 2



- Once the spring bar is released, pull out the other end to detach the strap.

To reassemble your device, follow these instructions in reverse order.