

Insignia Flex 8 NS-15AT08 Back Casing Replacement

This guide shows you how to remove the back casing of the device.

Written By: Krystal Rhodes



This document was generated on 2020-11-26 07:53:34 AM (MST).



• iFixit Opening Tools (1)

Step 1 — Back Casing





- Insert a plastic opening tool into the seam between the back casing and the screen to separate the back casing from the tablet.
- You may need to use a metal opening tool for extra prying power, but beware that it can scratch your device or damage the internal components if the tool is inserted too deep.
- You will hear the tabs pop as you separate the back casing around the tablet.

Step 2





- Lift the back casing away from the rest of the device which should include the exposed circuit board and screen.
- Set the casing aside.

To reassemble your device, follow these instructions in reverse order.