



Insignia NS-CLLT01 Top Casing Removal

This guide will serve as a prerequisite guide for all of the other guides for this device.

Written By: Morgan Mattingly



INTRODUCTION

This guide will show users how to open the casing of the Insignia NS-CLLT01 in order to make necessary repairs.

TOOLS:

- [Phillips #2 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Insignia NS-CLLT01 Top Casing Removal



- Lift the four adhesive covers on each of the corners on the bottom of the clock using a plastic opening tool or your fingernail.

Step 2



- On the bottom of the clock, use your fingernail to push the battery cover to the right.
- Lift the battery cover up and to the right to reveal the batteries.

Step 3



- Remove the two AA batteries by pressing the end opposite of the spring towards that spring and lifting up.
- Once the batteries are removed, close the cover.

Step 4



- Use a long Phillips #2 screwdriver to unscrew all six 10mm Phillips screws inside the bottom of the clock.
- Turn over the device to allow the screws to fall out, being careful to catch them so that you do not lose any.
- ⓘ The screws may not come out of the bottom of the clock. As long as you have unscrewed them, the clock can still be opened.

Step 5



- Turn the clock back over.
- Lift the top off of the clock by gripping the back of the iPhone dock and pulling straight up.