



Fujifilm X-M1 Battery Replacement

This guide will help you replace the battery in the Fujifilm X-M1.

Written By: Kelsea Weber



INTRODUCTION

Camera not turning on? The battery may need to be recharged or replaced. Use this guide to replace the battery and get back to taking awesome photos!

Step 1 — Battery



- Turn the camera upside down to locate the battery compartment.
- Slide the button up to open the compartment.
- Slide the orange button up to release the battery.
- ⓘ The battery is not shown in these photos.

To reassemble your device, follow these instructions in reverse order.