



# Eton FRX3 Rechargeable Battery Pack Replacement

Replace the rechargeable Battery pack on the Eton FRX3.

Written By: Kenneth Sills



## INTRODUCTION

The Eton FRX3 uses a single internal, rechargeable nickel-metal hydride battery. Unfortunately, this battery may not last forever and will slowly lose its ability to hold charge over time. But luckily, swapping it out for a brand new one doesn't even require a screwdriver!

## Step 1 — Rechargeable Battery Pack



- Pull the plastic tab on the battery compartment cover panel to loosen it, then pull the panel off.

## Step 2



- Disconnect the battery pack wires from the device and remove the battery pack.

To reassemble your device, follow these instructions in the reverse order.